



C 359S Integrated Amplifier
Quick Setup Guide









1.



2.


BT ANT
WIFI ANT
LAN
HDMI eARC
SERVICE
OPTICAL
PHONO IN
LINE 1
LINE 2
SUBW
80Hz HI-PASS OFF
SOFT CLIPPING OFF
SPEAKER
CLASS 2 WIRING
RIGHT
LEFT
POWER
ON
WIFI MAC:
BT MAC:
Serial No./N° de série
2
1


NAD
Integrated Amplifier C 359S
PHONES
PHONO
LINE 1
LINE 2
OPTICAL
HDMI
BLUOS
BASS
TREBLE
BALANCE
3
4
5

DOWNLOAD

nadelectronics.com/product/C-359S-integrated-amplifier
support.nadelectronics.com

NETWORK SETUP

Connect your C 359S to your home network via **Wired** or **Wireless** connection.

A. WIRED CONNECTION
Using an Ethernet cable (not supplied), connect one end to C 359S's LAN port and the other end directly to your home network or router.

B. WIRELESS CONNECTION
Connect C 359S to your wireless network using any of the following three methods.

1 Wireless Accessory Configuration (WAC) using iOS/iPadOS device

2 Using iOS/iPadOS device

3 Using Android device

Condition: C 359S must be at hot spot mode. C 359S default setting is at hot spot mode.

IMPORTANT!

- *The following procedures may change over time without notice. Always check the C 359S product page for the latest updates.*
- *The BluOS app for iOS and Android devices, as well as for Windows and macOS desktops, can be downloaded from their respective application stores and also from NAD downloads at https://nadelectronics.com/downloads.*

1 WIRELESS ACCESSORY CONFIGURATION (WAC) USING iOS/iPadOS DEVICE

Wireless Accessory Configuration (WAC) setup mode is supported by iOS/iPadOS application. At WAC setup mode, network name and password are not required for the C 359S to be connected to your network.

a Select **Settings** menu of your iOS/iPadOS device.

b Go to **Wi-Fi** and select the network you would like to use with your C 359S.

c Scroll down to **SETUP NEW AIRPLAY SPEAKER**. Select your C 359S player indicated by **C359S-xxxx** where **xxxx** corresponds to the last 4 digits of the MAC (Media Access Control) address* of your C 359S.

d When **AirPlay Setup** screen comes up, select **Next**. Note that you can also customize the name of your C 359S by entering desired name in the line item **Speaker Name**.

e Airplay Setup will proceed automatically. Follow setup process until **Setup Complete** is shown. Select **Done** to exit setup mode.

f Open BluOS App and select the configured C 359S. Follow the on-screen prompt to complete the setup process.

2 USING iOS/iPadOS DEVICE

a Open BluOS App. Select **Players** icon in the bottom portion of the App.

b From upper right corner of the App, select **+** to launch Easy Setup Wizard.

c From **My Players** screen prompt, select your C 359S's unique network ID* under **Needs Setup**.

d When **AirPlay Setup** screen comes up, select **Next**. Note that you can also customize the name of your C 359S by entering desired name in the line item **Speaker Name**.

e Airplay Setup will proceed automatically. Follow setup process until **Setup Complete** is shown. Select **Done**.

f C 359S will automatically enter **Looking for Upgrade** mode. If a firmware upgrade is available, it will be installed automatically. Once the upgrade is finished, select **Finish** to exit setup mode.

* The C 359S's unique network ID is listed as the product name (i.e., C359S) immediately followed by the last four digits in the MAC (Media Access Control) address (example: C359S-ACF7).

3 USING ANDROID DEVICE

a Open BluOS App.

b BluOS will automatically search for available players.

i. A prompt will appear indicating **New Players detected**.
   - Select Setup now. The available players will be listed under **My Players**. Choose the C 359S (identified by its unique network ID*) marked **NEEDS SETUP**.

ii. If not prompted, select **Players** icon in the bottom portion of the BluOS App.
   - From the upper right corner of the BluOS App, select + to launch Easy Setup Wizard. The app will begin **Looking for Players**.
   - Select the unique network ID* of your C 359S from the **My Players** window.

c Select your Home Wi-Fi Network from the **Choose WiFi Network** drop down menu.

d Enter your home network's Wi-Fi **Password** in the field provided and select **Continue**.

e Select or enter preferred **Name** to customize your C 359S for easier identification in the Player Drawer. Select **Continue**.

f Network setup process proceeds automatically. As it advances, it will automatically enter **Looking for Upgrade** mode. If a firmware upgrade is available, it will be installed automatically.

g Network setup process is completed when **Setup Complete** is shown in the App. Select **Finish** to exit the setup process.

©2026 NAD ELECTRONICS INTERNATIONAL, A DIVISION OF LENBROOK INDUSTRIES LIMITED
All rights reserved. NAD and the NAD logo are trademarks of NAD Electronics International, a division of Lenbrook Industries Limited.
No part of this publication may be reproduced, stored or transmitted in any form without the written permission of NAD Electronics International.
C 359S QSG 08 - 10/26